

KIT-1

Parts Included:

□ (5) SJ-1 Spider Joints
☐ (2) UMB-1 Universal Mounting Bases
☐ (1) 1" to ½" slip fit schedule 40 reducer bushing
☐ (1) 4" piece of ½" schedule 40 PVC pipe
☐ (1) 1" slip fit schedule 40 PVC cross fitting
☐ (1) 1" slip fit schedule 40 PVC Tee fitting
☐ (2) 1" slip fit schedule 40 PVC 90 degree elbow fittings
□ (24) #10 x 5/8" Self Drilling Screws
Materials we adod:
<u>Materials needed:</u>
☐ (12) Feet of 1" schedule 40 PVC pipe (Body will be approx. 5'10" tall)
☐ (1) Styrofoam wig head
☐ (1) Plywood base approx. 24" x 15" x 3/4"
Cut List:
□ A) Neck: (1) 4" piece of ½" pipe
□ B) Spine: (2) 7 1/8" pieces of 1" pipe
□ C) Shoulders: (2) 6" pieces of 1" pipe
D) Upper Arms: (2) 8 ½" pieces of 1" pipe
☐ E) Forearms: (2) 9 ¼" pieces of 1" pipe
☐ F) Hips: (2) 3 ¼" pieces of 1" pipe
☐ G) Legs: (2) 34 ½" pieces of 1" pipe

Helpful Hints:

Do not over tighten the self-drilling screws! Start with a drill, complete final tightening by hand.

Place the screws in the middle of the SJ-1 slots to allow the most adjustment in either direction.

Heavier loads may require a second screw to prevent slippage.

www.frightprops.com